Product Name: USB WiFi Repeater Extender
Model: GYH8116A
Wireless Network Extender User Manual

I. Instructions for Use

1. Power-On Startup: Connect the power supply and wait for the LED to blink before proceeding.
2. One-Touch Pairing: Press the WPS button on the router first, then press the extender’ s WPS button.
3. Manual Setup: Connect your smartphone to the extender’ s network, then access its web interface to configure the password.
4. Placement Position: Optimal placement is midway between the weak-signal area and the router.

II. Warning

⚠. Avoid Interference: Keep away from microwave ovens or large metal objects.
⚠. Heat Dissipation and Ventilation: Do not cover the device to prevent overheating.
⚠. Periodic Restart: If internet speed slows down, try power-cycling the device.
⚠. Water and Moisture Protection: Use indoors only in dry environments.

III. Feature Overview

1. Signal Enhancement: Amplifies weak signals to eliminate dead zones.
2. Seamless Roaming: Automatically switches between access points while moving, ensuring uninterrupted video streaming.
3. Dual-Band Concurrent Operation: Simultaneously supports both 2.4 GHz and 5 GHz bands for faster speeds.

IV. Frequently Asked Questions (FAQs)

1. Cannot Connect to the Internet: Verify that the main router is connected to the internet normally.
2. Slow Speed: The extender may be too far from the main router; relocate it closer.
3. LED Turns Red: Signal strength is insufficient; reposition the device and reconfigure.