LED数字钟说明书

适用于：DS - 6668/5510

主要功能

①、多信息显示：时间、星期、温度、湿度同屏显示


②、亮度可调：1，自动感光调整亮度，2，手动调整亮度

③、闹铃功能：两组闹铃 带单/双休/每天闹铃 .带贪睡功能

④、正计时和倒计时功能：最长99分59秒

⑤、DVSV供电(常亮显示)或3节AAA电池供电(按键唤醒显示)

⑥、夏令时



综合设置

1.常规设置：



2.亮度调节：时间状态下，短按 “+” 键切换亮度与模式，“L - AU”三档自动感光；“L - SL”带睡眠模式四档自动感光；“L - 01”低亮度；“L - 02”中亮度；“L - 03”高亮度。

3.温度单位设置：时间状态下短按 “㊀” 切换 “℃/℉”。

4.夏令时：长按 “㊀” 开/关夏令时同时显示/关闭 “DST”。

闹钟设置

1.开关闹钟：短按 “🔔” 键显示 “🔔” 图标和闹钟时间 “ ”，再按 “🔔” 键 “🔔” 图标和闹钟时间 “ ”

再按 “Set” 键进入对应组别闹钟设置。



2.关闭闹钟：当闹钟响起，长按任意键关闭本次闹钟，进入下次闹钟状态。短按任意键启动贪睡。

计时设置

正计时：短按 “START/STOP SNOOZE” 键显示 “ 00:00 Seconds ”，再按 “START/STOP SNOOZE” 启动正计时,再按



Chinese

LED Digital Clock Instruction

Application: DS-6668/5510

Main Functions

① Multi-information display: time, week, temperature, humidity display on the same screen.

② Brightness adjustable ☼automatic photosensitive adjustment;


☼ Manual adjustment.

③ Alarm function: two alarms with single off / double off / daily alarm, snooze function

④ Timing and countdown function: up to 99 minutes and 59 seconds


⑤ DC5V power supply (normally bright display) or 3 AAA battery power supply (key wake-up display)

⑥ daylight-saving time



Comprehensive Settings

1. General setting:



2.Brightness adjustment: Under the state of time, short press the “ + ” key to switch brightness and mode, - L - AU- and the three levels of automatic sensitivit,-“L - SL - With sleep mode four automatic light sensitive, - L - 01 - low brightness, - L - 02 - Medium brightness , - L - 03 - high brightness

3.Temperature unit setting in the time state, short press “㊀” to switch” C/°F

4 . DST Settings:Long press “㊀” to enable or disable the DST and display or disable DST.

Alarm Settings

1. Switch alarm clock: short press “🔔” to display “🔔” icon and alarm time “ ”, press again “🔔” icon and alarm time”

then press “Set” to enter the alarm setting of the corresponding group.



2.Turn off the alarm clock: When the alarm clock rings, long press any key to turn off the alarm clock and enter the next alarm clock. short press any key to activate snooze

Timing Settings

Timing: short press “START/STOP SNOOZE” to display “ 00:00 Minute Second ”, press “START/STOP SNOOZE” again to start timing, press “START/STOP SNOOZE” again to stop timing,and so on, long press reset exist and return to time state.

Countdown: short press 66 START/STOP SNOOZE to display “ 66 Minute Second ” press 66 to enter the count down time and light up the countdown icon “⏲”

Short press 66 START/STOP SNOOZE to start countdown, press 66 START/STOP SNOOZE ' again to stop, and so on.

Long press 66 START/STOP SNOOZE 1 "to reset exist and return to time state.

English

LEDデジタル時計取扱説明書

適用対象：DS - 6668/5510

主な機能

①、多情報表示時間、曜日、温度、湿度同画面表示。

②、明るさは調節できます。①自動感光で明るさを調節します。

②手動で明るさを調節します。

③、日常表し時計機能二組の日常表し時計はシングル/

双休/毎日アラーム、スリープ機能付き。

④、正計時とカウントダウン機能最長99分59秒です。

⑤、DC5V電源（常時点灯表示）または3つのAAAバッテリー電源


（キーをスリープ表示）

⑥、サマータイム



統合設定

1.一般設定：



2. 明るさ調節: 時間状態で「+」キーを短く押して明るさとモードを切り替え.「L - AU」は自動感光.「L - SL」睡眠モードは自動感光.「L - 01」低明るさ.「L - 02」中明るさ.「L - 03」高明るさ.

3. 温度単位設定: 時間状態で「㊀」キーを長く押して温度単位摂氏/華氏表示切り替えます。

4. サマータイム設定: 時間状態で「㊀」キーを長く押して、サマータイムをオン/オフし、同時に「DST」アイコンを表示/オフします。

アラーム設定

1. アラームを設定する：「🔔」キーを短く押すと、「🔔」アイコンと目覚まし時計の状態 「🔔」アイコンと目覚まし時計の状態」「㊀」キーを押して該当するグループのアラーム設定に入り、



2. 目覚まし時計をオフにする 目覚まし時計が鳴ったら、任意のボタンを長押しして今回の目覚まし時計を閉じる 次の目覚まし時計状態に入ります。任意のボタンを短く押すと、スリープが始まります。

注意：上記の「長押し」は3秒長押しです。

タイマーの設定

Countup: Press SNOOZE to activate. 00:00 Minutes Displays0, press “START/STOP SNOOZE” to start timing, press “SNOOZE” again to stop timing, and so on, long press reset exist and return to time state.

Press it again to cancel.If you repeat this process and press and hold START/STOP SNOOZE, it will return to the original state.

Press START/STOP SNOOZE to display "00:00", then press the "0" button and power off.

Enter the time and the "Countdown" light will turn on simultaneously.

Press START/STOP SNOOZE and then press START/STOP SNOOZE again to stop it

If you keep repeating this, pressing and holding the "START/STOP SNOOZE" button will reset to the original state.

Japanese

LED Digital Clock Instruction

Adatto per: DS-6668/5510

Funzioni Principali

① Visualizzazione di più informazioni: ora, giorno della settimana, temperatura, umidità in sullo stesso schermo.


② Luminosità regolabile: ① regolazione automatica della luminosità ambientale alla luce. ② regolazione manuale della luminosità.

③ Funzione di sveglia:due gruppi di sveglia con sveglia fine settimana singolo giorno/due giorni/giornaliera, con funzione sonnellino.

④ Temporizzatore positivo e funzioni di conto alla rovescia: fino a 99 minuti e 59 secondi

⑤ Alimentatore DC5V (display normalmente luminoso) o alimentazione a 3 batterie AAA (display di riattivazione chiave)

⑥ Ora legale



Impostazioni complete

1. Impostazioni generali:



2. Regolazione della luminosità: ci sono tre stadi del tempo, premere brevemente il tasto "+" per commutare la luminosità de la modalità. "L - AU" sensibilità della luce automatica a 3 livelli; "L - SL" sensibilità dautomatica a 4 livelli con modalità dsi sospensione; "L - 01" bassa luminosità o "L - 02" media luminosità o "L - 03" alta luminosità o

3. Impostazione dell'unità di misura della temperatura: premere a lungo il tasto "㊀" per cambiare l'unità di misura della temperatura Celsius / Fahrenheit nello stato ora.

4. Impostazione dell'ora legale: premere a lungo il tasto " ㊀ " nello stato dell'ora, per attivare/disattivare l'ora legale e visualizzare/disattivare contemporaneamente "DST".

Impostazione della sveglia

1. Attivazione/disattivazione della sveglia: premere brevemente il tasto "🔔" per visualizzareicona" 🔔 e ora della sveglia", quindi premere il tasto "icona 🔔 e ora della sveglia". Quindi premere il tasto "Set" per accedere all'impostazione del gruppo di sveglie corrispondente.



2. Spegnimento della sveglia: quando la sveglia suona, premere a lungo un tasto qualsiasi per spegnere la sveglia e passare allo stato successivo. Premere brevemente un tasto qualsiasi per avviare il sonnellino.

Timing Settings

Press and hold the "START/STOP" button for a long time to clear the zero and exit the return time state.

Countdown: Briefly press the "START/STOP SNOOZE" button to display 00:00 minutes seconds and press the "+" button to

Enter the countdown time. At the same time, the countdown icon will "⏲"

Turn it on. Press the "START/STOP SNOOZE" button to restart the timing, then press the START/STOP SNOOZE button to pause the cycle.Press and hold the "START/STOP SNOOZE" button to clear zero and exit the state. of the return time.

Italian

LED Digital Clock Manual

Applicable to: DS-668/5510

Main functions

① Display of multiple information: time, week, temperature, humidity on the same screen

②Adjustable brightness: ☼Automatically adjusts to the light to adjust the brightness.

☼Manual brightness adjustment.

Alarm clock function: two sets of alarm clocks

with one/two-day/daily alarm, with snooze function

③Timer and countdown function: Up to 99 minutes and 50 seconds.

④Power supply:DC5V (normally bright display) or power source

3 AAA battery power (key activation screen)

⑤Summer



Comprehensive configurations

1.General configuration:

2. Adjustable: press the button + to change the brightness and time mode, -R

3-speed automatic light sensitivity, with sleep mode and automatic light sensitivity

four-speed: low brightness, medium brightness, high brightness. L - 03

3.Ajustedelaunidadedetemperatura: Presionedurantemuchotiempoelbotón" "enl estadodelahoraparacambiar launidaddetmu

4Ciiodoreurect "in the time state to activate/deactivate the "DST" icon at the same time.4. Sometimes: The "D" symbol is in the "time state" and is not being adjusted.

Wake-up settings

1.Turn the alarm clock on and off: Briefly press the button to display the alarm icon.

"Icon and alarm clock status Press the icon and alarm clock status button again";

Press the "Set" button to enter the wake-up settings for each corresponding group.

adjust the hours

adjust the minutes for the double?Alarm or daily alarm, it will be displayed from Monday to the corresponding Sunday

2. Turn off the alarm clock: when the alarm clock rings, press the button for a long time.

to turn off this alarm clock and enter the next alarm clock.Press any key for a long time to turn off this alarm clock

Note: The "long press" mentioned above is a press that lasts for three seconds.

Timer Configuration

Timer: Briefly press the "START/STOP SNOOZE" button, 00:00 is displayed: Press the "START/STOP SNOOZE" button.

To start the timer, press the "START/STOP SNOOZE" button again to pause.

It circulates in this way, keep pressing the START/STOP SNOOZE button to reset, exit and return to the state.

time. Countdown timer: Briefly press the START/STOP SNOOZE button, " ' " is displayed. Press

Press the "/" number buttons to enter the countdown time. At the same time, the minutes/seconds icon lights up.

Countdown of 2": Press the "START/STOP SNOOZE" button to start the countdown.Press the button again

"START/STOP SNOOZE" For pause. Keep pressing the "START/STOP SNOOZE" button in this way to reset. exit and return to the time state.

Spanish

User Manual for the LED Digital Clock

For: DS-6668/5510

Main Functions

① Multi-Information Display: Time, Week, Temperature and Humidity 2 MON TUE WED THU F SAT SUN on the same screen

② Adjustable Brightness: ☼automatic light sensitivity for Brightness adjustment; ☼manual brightness adjustment.

③Alarm clock function: two alarm clocks with single/dual Daily alarm, with snooze function

④Positive and countdown timer function: Maximum 99 minutes and 59 seconds

⑤DC5V power supply (usually bright display) or 3AAA battery power supply (button wake-up indicator)

⑥Summer

Comprehensive settings

1.General Settings

The "Set" button adjusts the 12/24-hour system and sets the clock and minutes.



short press + short press + press to exit the setting

2.Ilisckiieamiltgtunuinc 3-Gang - AU

automatic light sensitivity, L"with sleep mode and automatic light sensitivity

L = low brightness, 02-medium brightness, high brightness.

3.Temperatureinheitseinstellung:Drücken Sietangente "-"lange,umzustandsmodeTemperatureinheit.Celsius/Fahrenheit zuwechseln

4.Clock alarm clock: Briefly press the Alarm Setting 1 button to display the "Symbol and Alarm Status" icon.

Press the button again. It displays the symbol "2" for symbol and alarm status.

Press the "Set" button to access the alarm settings for the corresponding group.

Press and hold the AL OF button + ⊖ briefly to turn the alarm on/off.

Drücken Sie lang oder kurz Taste, Drücken Sie lang oder kurz Taste, um Montag bis Sonntag zu drücken, um die Minute zu drücken, um die Minute zu drücken

short + button to set the short + button for the alarm clock.From Monday setting the clock, setting the minute until Sunday will be done accordingly

2. Turn off the alarm clock: When the alarm clock rings, press and hold any button to turn off the alarm.

and set the next alarm clock.Press any key to start the snooze.

Note: The aforementioned "long press" is a long press for three seconds.

Time measurement settings

Positive time measurement: Press the START/STOP SNOOZE button "briefly to display" 00:00, press the "START/STOP SNOOZE" button to activate the

Start timing, then press the START/STOP SNOOZE button to pause. So, during a cycle, press and hold the button.

START/STOP SNOOZE, to reset to the zero point and return to the time mode.

Countdown time: Briefly press the 'START/STOP SNOOZE' button to 'display the digits' / 'press to activate'.

Enter the countdown time. At the same time, the countdown symbol "L" lights up.

Press the "START/STOP SNOOZE" button to start the countdown, then press the "START/STOP SNOOZE" button to pause, and so on.

Press and hold the "START/STOP SNOOZE" button to reset the zero point and return to the time mode.

German

Manual of the LED Digital Clock

Suitable for: DS-6668/5510

Main function

① Multi-information display: time, week, temperature and humidity on the same screen.

② Adjustable brightness: ☼automatic sensitivity to light

to adjust the brightness. ☼manual brightness adjustment.

③ Alarm clock function: two sets of alarm clocks with alarm sound.

single/two days/daily, with snooze function

④ Timer and countdown functions:

up to 99 minutes and 58 seconds.

⑤DC5V power supply (normally illuminated) or

3 AAA battery power supply (key wake-up display)

⑥Summer time

Parameter settings

1.General Parameters:

00:00 7 24H briefly press 00:00 briefly press 00:00 Press

In the time setting mode, long press the Set key to adjust the time to 12-hour/24-hour format. Short press Set to adjust the te ovement

la minute

2023 briefly press A D briefly M briefly press Set

Press briefly on Set to adjust. Press briefly on Set again to adjust. Press briefly to exit the setting

the year the month the date

2.Brightness adjustment: Press the "+" key to change brightness and mode in time mode, sensitivity to the automatic light with 3 speeds - AU - L - With automatic light sensitivity and four-speed settings in standby mode low brightness, medium brightness, high brightness L-0

3.Rélageduitédetempérature:Appuelogouemnturlebouton "iéttmorelpourcomutrltédetmatureluse

4.Releuderudt:ppuelogouemnturiatouche "dansle cadeurepouractiver/desctiverlce"l"

Alarm clock setting

1.To set the alarm clock: Briefly press 66 9 it will display 66 and the alarm clock status. "Press agai in short -

= Change the alarm clock setting" press Set to enter the alarm clock setting.

Press the " " key to set the alarm.

00: Appuyez 0 Appuyez 0 8-40

la minute Select to enter weekend modes / every day "7" means every day

2.Turn off the alarm clock: When the alarm clock rings, long-press any key to turn it off.

This alarm turns any key to start the snooze.

Note: The &long press> mentioned above is a long press for three seconds.

Synchronization settings

Timing: Briefly press START/STOP SNOOZE, it will display 00:00;, then press START/STOP SNOOZE to start the timer.

Timing, press START/STOP SNOOZE again to pause.Press and hold START/STOP SNOOZE to erase.

all the data and return to the time state.

Countdown: Briefly press START/STOP SNOOZE, it will display 00:00, briefly press the button to

Enter the countdown time. At the same time, the minutes-seconds countdown icon lights up."

Press START/STOP SNOOZE to start the countdown, and press START/STOP SNOOZE again to stop it.

Pause: Long press START/STOP SNOOZE) to erase all data and return to the time setting state.

French

PKOBOCBBOB

Product Name: DS-6668/5510

OCHOBHble yHKuN

① Operating hours: Mon, Tue, Wed, Thu, Fri, Sat, Sun 8 hours

② Product Description: ① Automatic product description;

③yHKu 6yAbHKa: ABa KOMnoHeHTa 6yAbHKOB C

④ cnoKNTeobHble yHKu BpeMeH other OTcuea: Ao 99 MNHyT

⑤He nOcHHro Oa B HOpaHo pK pe) O

⑥ NiTaet 3 aape AAA (pr-cnne npoueH)

⑦ JeTHA nopa



KoMneeKCHble HacTpoKn

1. Linisexe

KOpOTKO A KOPOTKO A KOpOTKO A BbIXOAa N3 HCoeK

perynposKi Hoi perynpoBK Mecali perynpoBKi x

2.PerOBK pKO T:B HeHHOCOCOH He KHOn"+n KOCT M,

TpexCTyneHaTa aBTOMaTNeCKa CBeTOyBCTBTenbHOCTb 3 HBFOMaTnueckan

CBeTOyBCTBNTenbHOCTb B peNMe CHa; H3Kb PKOCT 1";ce

"BICOKaapKOC

3. Product Description: B COCTOH iBpeMeH HaMNTe KHOnKy "+ B TeUeHNe KOpOTKOrO BpeMeHN,"

1 TpexKopoTKix byoT tOKnbpeMn H BbIGaTb HacTpoiKu Lkna.

4.HoHO pNM: 22:00-06:00 ApKOCTb aBTOMaNeckK nepexOAT B pM H3KO apKOCTN.

Hacrpoüka 6yAbHKa

1.KopeKoHne 6yHKa: 1.KopoTKo HaMTe KaBwy "/ TbI noKa3aTb ① 3Ha4OK BeM

6yanbHKa',3aTeM HaMTe>HaBb BpeM 6yHKaa 3aeM HaMTe KnaBwy Set)"

4Tbl BOT B HaeK pHKa COCTOHe CBye mnM

RL KOpOTKO HaMTe KHOnKy "+/-,uTobI nepeKIOTb 6yblHK

"00:00 HaXMuTe 00:00

KOpOTKO A KOpOTKO A BbIXOAHbIM/eeAHeBHbIM 6yANbHNKOM; *7"3Ha4MT eeAH

perynpoBKn-kaCtB perynpOBKN MNHYT Aarto HaxMn 6yan pnpaBTbCa

*,uTObI BBecTN BpeM OSpaTHOro OTCeTa

HaXMMTe KHOnKy START/STOP SNOOZE "uTobI HaaTb opaTHb OTCueT,3aTeM HaMTe KnaBwy START/STOP SNOOZE ",uTobicenaTb

Now, there is no problem. The START/STOP SNOOZE function works well.

Русскнû